














































Name	Picture	Description	Cat. number
Automatic tool grinder ANB-5T		Thick Turret Die size „D”. 	VI00008549
ADAPTER “T1”		Trumpf Die size „1” Trumpf Punch size „1” and „2”. 	VI00001187
ADAPTER “T2”		Trumpf Die size „2” Trumpf Punch size „1” and „2”. 	VI00001908
ADAPTER “TS-1”		Whisper or RoofTop Trumpf Punches angle 1°. Necessary to use adapter “T1”. 	VI00001799
ADAPTER “TS-2”		Whisper or RoofTop Trumpf Punches angle 2°. Necessary to use adapter “T1”. 	VI00001722
ADAPTER “TS-3”		Whisper or RoofTop Trumpf Punches angle 3°. Necessary to use adapter “T1”. 	VI00001723
ADAPTER “TS-4”		Whisper or RoofTop Trumpf Punches angle 4°. Necessary to use adapter “T1”. 	VI00001724

TRUMPF

<p>ADAPTER "TS-5"</p>		<p>Whisper or RoofTop Trumpf Punches angle 5°. Necessary to use adapter "T1".</p> 	<p>VI00001190</p>
<p>ADAPTER "TS-7"</p>		<p>Whisper or RoofTop Trumpf Punches angle 7°. Necessary to use adapter "T1".</p> 	<p>VI00001806</p>
<p>ADAPTER "TS-8"</p>		<p>Whisper or RoofTop Trumpf Punches angle 8°. Necessary to use adapter "T1".</p> 	<p>VI00001393</p>
<p>ADAPTER "MT4"</p>		<p>Trumpf 4 position Multitool Die and Punch. Necessary to use adapter "T1".</p> 	<p>VI00001714</p>
<p>ADAPTER "MT3/6"</p>		<p>Trumpf 3 or 6 position Multitool Die and Punch. Necessary to use adapter "T1".</p> 	<p>VI00001715</p>
<p>ADAPTER "MT5"</p>		<p>Trumpf 5 position Multitool Die and Punch. Necessary to use adapter "T1".</p> 	<p>VI00001560</p>
<p>ADAPTER "MT10"</p>		<p>Trumpf 10 position Multitool Die and Punch. Necessary to use adapter "T1".</p> 	<p>VI00001394</p>
















TRUMPF

TRUMPF

<p>ADAPTER "A0"</p>		<p>Thick Turret Die size „C“ and Punch size „D“.</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>C</p>  <p>Ø 88,9 - 30</p> </div> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>D</p>  <p>Ø 89,4 - 84,2</p> </div> </div>	<p>VI00001747</p>
<p>ADAPTER "AB"</p>		<p>Thick Turret Dies size „A“, „B“ and Punch size „A“. Necessary to use adapter "A0".</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>B</p>  <p>Ø 47,62 -</p> </div> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>A</p>  <p>Ø 25,39 - 30</p> </div> </div> <p style="text-align: center;">Ø 16 - 118</p>	<p>VI00001748</p>
<p>ADAPTER "BC"</p>		<p>Thick Turret Punch size „B“ and „C“. Necessary to use adapter "A0".</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>B</p>  <p>Ø 31,75 - 100,5</p> </div> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>C</p>  <p>Ø 51 - 96</p> </div> </div>	<p>VI00001720</p>
<p>ADAPTER "ER" <i>not for PNB-2E !</i></p>		<p>Thick Turret Punch size „E“. Necessary to use adapter "A0" or adapters "AS -...."</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>E</p>  <p>Ø 114,8 84,2</p> </div>	<p>VI00002358</p>
<p>ADAPTER "EM" <i>not for PNB-2E !</i></p>		<p>Thick Turret Die size „E“.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>E</p>  <p>Ø 158,74 - 30</p> </div>	<p>VI00002359</p>
<p>ADAPTER "MT24"</p>		<p>Multitool 24mm Die and Punch. Necessary to use adapters "A0" + "AB".</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>MT24</p>  <p>Ø 31 - 24</p> </div> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>MT24</p>  <p>Ø 24 - 70,5</p> </div> </div>	<p>VI00001903</p>
<p>ADAPTER "MT16"</p>		<div style="border: 1px solid black; padding: 5px; text-align: center;">  <p>Ø 25,39 - 18</p> </div>	<p>VI00001792</p>

THICK TURRET

THICK TURRET

<p>ADAPTER "MT8"</p>		<p>Multitool 8mm Die and Punch. Necessary to use adapters "A0" + "AB".</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>MT₈</p>  <p>Ø 16 - 17</p> </div> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>MT₈</p>  <p>Ø 8 - 70,5</p> </div> </div>	<p>VI00001746</p>
<p>ADAPTER "AS-1"</p>		<p>RoofTop or Whisper Thick Turret Punches angle 1°.</p> 	<p>VI00001801</p>
<p>ADAPTER "AS-2"</p>		<p>RoofTop or Whisper Thick Turret Punches angle 2°.</p> 	<p>VI00001716</p>
<p>ADAPTER "AS-3"</p>		<p>RoofTop or Whisper Thick Turret Punches angle 3°.</p> 	<p>VI00001717</p>
<p>ADAPTER "AS-4"</p>		<p>RoofTop or Whisper Thick Turret Punches angle 4°.</p> 	<p>VI00001718</p>
<p>ADAPTER "AS-5"</p>		<p>RoofTop or Whisper Thick Turret Punches angle 5°.</p> 	<p>VI00001719</p>
<p>ADAPTER "AS-6"</p>		<p>RoofTop or Whisper Thick Turret Punches angle 6°.</p> 	<p>VI00002235</p>
<p>Spare Grinding Wheel</p>			<p>24S094021_0000 08</p>
<p>Cooling liquid Grindex10, 940ml</p>		<p>Cooling liquid concentrate. For cca 30l cooling medium.</p>	<p>VI00004626</p>

THICK TURRET